

Warranty Card

Thank you for your trust and support for MEGAKEY products. MEGAKEY will provide you with a year after-sales service free of charge (freight is not included). In order to protect your legal rights and interests, please do not alter this warranty service card without authorization. If you need services or have any questions, please consult the dealer or contact us.

After-sales service is provide within 12 month, please see details as below:

You shall go to the purchase store, carry the product, all accessories and packaging (intact), In case of quality problems within 7 days, replace with a new one or apply for full refund. In case of quality problems within 15 days, replace with a new one. In case of quality problems after 15 days, apply for after-sales maintenance. In case of any damages caused by personal reasons, the repair costs shall be charged.

The followings are not included in this warranty service:

- 1.Products with damaged appearance, missing LOGO or exceeding the service period.
- 2.Products that have been disassembled, bumped, repaired, modified with missing parts.
- 3.Products with burnt circuit or damaged power cable and interface.
- 4.Products damaged by foreign matter intrusion (including but not limited to various of fluid, wind, sand, dust, soot, etc.)

Purchase Date	Purchase Store
Repair Date	Repair Descriptions

Daily Maintenance of Mechanical Keyboard

The mechanical keyboard is only a switch under each key structurally. From the structure itself, it is must be far away from the dust, beverages, oily water to prevent key failure or circuit board damage in daily use.

1.Precautions for dust: Avoid heavy dusts, such as soot, falling into the keyboard. If soot or other dust falls into the keyboard, you must pull out the key cap by a vacuum cleaner and a brush, and clean it while brushing. Don't turn the keyboard over and beat it without removing the key cap, avoid more dusts to enter the shaft body or any damages.

2.Usage of cleaning mud for keyboard: It is prohibited to press the whole piece of cleaning mud directly on the keyboard. Please clean the dusts on the surface of the key cap gently, then pull out the key cap, take a small piece of cleaning mud and knead it into a ball, roll it in the gap of the shaft body and stick the dusts clean.

3.Precautions for keyboard with liquid entering: If any kind of fluid falls into the keyboard, please quickly make the keyboard power off, dry the keyboard for about 2 hours by a hair dryer or a large drying box, (avoid blowing the keyboard directly from the mouth of the hair dryer close to the keyboard, otherwise the keyboard shell will be deformed due to high temperature). In case of fluid intrusion outside of clean water, if the shaft body has problems after drying, please contact the after-sales service as soon as possible.

A good keyboard not only provides you with excellent entering experience and fun, but also requires your careful care. Keep away from soot and liquid to ensure the normal use of the keyboard. The correct handling method can protect your keyboard in case of an accident, and avoid irreversible damages.

Note: The final interpretation right of this product belongs to the brand of MEGAKEY.

Brand Introduction

MEGAKEY
It is the independent peripheral brand of Dongguan Zhongke Yunchuang Electronic Technology Co., Ltd. Including medium and top brands suitable for various users. Focus on innovative design and manufacturing of e-sports peripherals for years.

Brand Applications

Provide services for medium and top brands.
Meet the young generation with strong personalized desires. Focus on traditional PC and new mobile e-sports users. Bring you more functional peripherals, more popular cultural and artistic connotation.




MEGAKEY Quick start guide

MK901 mechanical keyboard

Characteristics of Signal

Setting of Interface (USB) pin signal:



This keyboard is a USB 2.0 game keyboard, conforms to the USB2.0 specification, and it is compatible with USB2.0 and USB1.1 devices.

Net Weight and Size:

Length: 440.60mm, width: 135.80mm, height: 36.40mm
Fix method: screw locking
Net weight: 0.6kg

Main materials

Shaft: metal panel
Lower lid: ABS
Shaft switch: mechanical shaft
Foot pad: silicone
Power cable: USB, 2.0 5-core cable

Ergonomics Design

This keyboard is adopted with an ergonomically inclined design and a stepped key cap to reduce human fatigues. The key caps have been oil sprayed and radium carved for light transmission characters.

Dear Users:

Thank you for choosing MEGAKEY products. Pleased to provide you with our mechanical keyboards and services. If you have any problems or suggestions for improvement, please contact us via our official blog and WeChat at any time. Any comments from you will be highly appreciated. Thank you again!

Custom Mode (record / save)

Press **Fn** + **0** or **Fn** + **9** to enter the corresponding custom mode.

(FN+End = record / save)

Press **Fn** + **End** to set " sparkling " state. Press any key to normal on or put off.

(M1-M3indication lamp is flashing)

Press **Fn** + **END** to save. **Fn** + **ESC** Remove light record restore to normal on.

(The record is finished.)

Light Mode (pre-record game mode)

Fn + **1** Game mode 1 (FPS) **Fn** + **HOME** Light mode: Sparkling

Fn + **2** Game mode 2 (CF) **Fn** + **DEL** Light mode: Glittering

Fn + **3** Game mode 3 (COD) **Fn** + **INS** Light Normal on

Fn + **4** Game mode 4 (RTS) **Fn** + **PGUP** Light mode: Swaying

Fn + **5** Game mode 5 (LOL full) **Fn** + **PGDN** Light mode: Twinkling

Fn + **6** Game mode 6 (Car Race) **Combination Keys of Light Shift (press each key for 4 times to reach 4 different light effects)**

Fn + **7** Game mode 7 (NBA)

Fn + **8** Game mode 8 (LOL short)

Fn + **9** Custom mode1

Fn + **0** Custom mode2

Fn combination Functions (Standard Shortcut Keys)

Fn + **F1** My computer **Fn** + **F2** Search

Fn + **F3** Calculator **Fn** + **F4** Player

Fn + **F5** Previous **Fn** + **F6** Next

Fn + **F7** Play/Pause **Fn** + **F8** Stop

Fn + **F9** Silent **Fn** + **F10** Volume -

Fn + **F11** Volume + **Fn** + **F12** Lock Unlock keyboard

Fn + **↑** Brightness + **Fn** + **↓** Brightness -

Fn + **→** Light speed + **Fn** + **←** Light speed -

Fn + **WIN-L** WIN-Lock+APP **Fn** + **ESC** ESC Default normal on

Fn + **SCRK** N keys (conflict free) **Fn** + **PRTSE** 6 keys (conflict free)